# VEHICLE SERVICE AGREEMENT GOLD

available through

MAZDA PROTECTION PRODUCTS



FINANCIAL SERVICES


# CRAFTED FOR CONFIDENCE







The Mazda Protection Products Vehicle Service Agreement (VSA) Gold helps protect you after your Mazda warranty expires. For more information contact your Mazda Dealer.



# **BUILT-IN BENEFITS**

- Protection after your Mazda warranty expires<sup>1</sup>
- 24/7 Roadside Assistance<sup>2</sup>
- Substitute Transportation
- Travel Protection
- Deductible Options<sup>3</sup>
- Repairs using Mazda-approved parts, performed by factory-trained technicians, keeping your Mazda at peak performance
- Transferable from owner to private party, one time at no additional cost

### **VEHICLE ELIGIBILITY**

#### **NEW VSA PLANS**

Mazda vehicles are eligible if less than 3 years old from date vehicle was first put into service and up to 36,000 total vehicle miles.

#### PRE-OWNED VSA PLANS

Mazda vehicles are eligible within current model year plus 9 prior model years and up to 200,000 total vehicle miles. See your dealer for eligibility requirements on non-Mazda vehicles. Pre-Owned Vehicle Plans available through your Mazda dealer only at the time of pre-owned vehicle purchase or lease.

## **COMPONENTS**

Mazda Protection Products VSA Gold covers the cost of mechanical breakdown of the components listed below.<sup>4</sup>

#### **ENGINE**

All internally lubricated components and: Balance Shaft; Camshaft; Crankshaft; Crankshaft Pulley; Cylinder Heads; Engine Block; Engine Mounts; Engine Oil Reservoir; Engine Oil Reservoir Pump; Equipment Drive Shaft; Exhaust Manifolds; Flexplate; Flywheel; Idler Pulley; Intake Manifold; Oil Pan; Oil Pressure Switch; Oil Pump; Oil Sending Unit; Piston; Seals and Gaskets; Supercharger; Supercharger Intercooler; Tensioners; Timing Belt; Timing Chain; Timing Cover; Timing Gears; Turbo Intercooler; Turbo Wastegate; Turbocharger; Valve Covers; Water Pump

#### MANUAL TRANSMISSION

Transfer Case Components (All internally lubricated components) and: Clutch Master Cylinder; Clutch Release Cylinder; Gears and Shafts; Hoses, Lines and Tubes; Seals and Gaskets; Shift Linkage and Cables; Transfer/Transmission Case; Transmission Mounts; Shift Lever Knob

#### **AUTOMATIC TRANSMISSION**

Transfer Case Components (All internally lubricated components) and: Hoses, Lines and Tubes; Seals and Gaskets; Shift Linkage and Cables; Solenoids; Torque Converter; Transfer/Transmission Case; Transmission Mounts; Vacuum Modulator; Shift Lever Knob

#### **AXLE ASSEMBLY**

(Front, Rear, Four-wheel and All-wheel Drive): All internally lubricated components and: 4x4 Actuators; Axles and Bearings; Center Support Bearing; Constant Velocity Boot Band; Constant Velocity Joints and Boots; Differential Carrier Assembly; Drive Axle Housing; Drive Shaft; Hubs; Locking Hubs; Seals and Gaskets; Thrust Washers; Universal Joints; Viscous Coupling

#### **SUSPENSION**

(Front and Rear): Bushings/Bearings; Control Arm Shafts; Electronic Suspension Actuator/Motor and Compressor; Radius Arm; Spindle; Spindle Support; Steering Knuckle; Sway Bar Link; Upper and Lower Ball Joints; Upper and Lower Control Arms

#### STEERING

Gear Box internal components and: Bushings/ Bearings; Center Link; Hoses, Lines and Tubes; Idler Arm; Pitman Arm; Power Steering Pump; Power Steering Pump Pulley; Rack and Pinion; Seals and Gaskets; Steering Column; Steering Column Coupling; Steering Column Shaft; Steering Dampener; Steering Gear Box and Pump Housings; Tie Rod End

#### **FUEL SYSTEM**

Air Flow Meter; Carburetor; Diesel Fuel Injection Pump; Electric Fuel Pump; Electronic Fuel Injection System; Fuel Injectors; Fuel Pressure Regulator; Fuel Pump; Fuel Sending Unit; Fuel Sensors; Fuel Tank; Throttle Body

#### **COOLING SYSTEM**

Cooling Fan Relay; Cooling Fan Sensor; Engine Cooling Fan Motor; Engine Fan; Engine Fan Clutch; Engine Fan Motor; Engine Fan Shroud; Fan Bracket Subassembly; Radiator; Seals and Gaskets

### AIR CONDITIONING/HEATING

Air Conditioning Lines and Tubes; Air Conditioning Pressure Switches; Air Temperature Control Programmer; Blower Motor; Blower Motor Resistor; Compressor; Compressor Clutch Assembly; Compressor Pulley; Condenser; Condenser Fan and Motor; Evaporator; Evaporator Temperature Sensor; Expansion Valve; Heater Control Head; Heater Control Valve; Heater Core; Idler Pulley; Pressure Regulator Assembly; Receiver/Dryer; Schrader Valve; Seals and Gaskets

#### **BRAKES**

Anti-Lock Braking/Traction Control Actuator, Pump and Motor; Brake Booster; Brake Hoses, Lines and Tubes; Disc Brake Calipers; Load-Sensing Proportioning Valve; Master Cylinder; Parking Brake Cable; Proportioning Valve; Seals and Gaskets; Wheel Cylinders

#### ELECTRICAL

Alternator; Automatic-Off Headlamp Sensor, Timer and Switches; Automatic Shoulder Belt Motor and Switches; Automatic Temperature Control Unit; Blower Motor; Blower Motor Resistor; Clutch Starter Interlock Switch; Convertible Top Motor; Cruise Control Actuator/Servo; Cruise Control Sensors and Switches; Cruise Control Vacuum Motor; Defogger Relay; Distributor; Engine Cooling Fan Motor; Headlamp Washer; Ignition Coil; Lamp Failure Indicator Sensor; Manually Operated Switches; Power Antenna Motor and Cable; Power Door Lock Actuator; Power Mirror Defogger; Power Mirror Motor; Power Seat Motors; Power Sliding Door Motor; Power Window Motor/ Regulator; Retractable Headlamp Motor; Smart Entry and Start System Switch, Sensor and Electronic Control Unit; Starter Motor; Starter Solenoid; Stop Light Switch; Sunroof Motor; Windshield Washer Pump; Wiper Motor

#### COMPUTERS AND ELECTRONICS

Anti-Lock Braking/Traction Control Computer and Sensors; Automatic Shoulder Belt Computer; Body Control Module; Cruise Control Computer; Electronic Ignition Unit; Electronically Controlled Transmission/Transfer Case Computer and Sensors; Electronically Modulated Suspension

Computer; Engine Control Computer; Knock Sensor; Power Mirror Electronic Control Unit; Power Seat Computer; Progressive Power Steering Computer; Sunroof Control Computer and Relay; Tilt/ Telescoping Steering Computer; Trip Computer; Vehicle Security Computers and Sensor; Wiper Module

## HYBRID/ALTERNATIVE FUEL

Actuator Assembly Shift Control; Hybrid Vehicle Generator Assembly; Hybrid Vehicle Motor Assembly; Hybrid Vehicle Transaxle Assembly; Transmission Input Damper Assembly; Battery Computer Assembly; Battery Current Sensor; Boost Charging Inlet and Plugin Electronic Control Unit; Circuit Breaker Sensor; Combination Meter Assembly; Combination Meter Computer; Fuel Cell Water Pump; Fueling Receptacle; Hybrid Vehicle Battery Blower Assembly; Hybrid Vehicle Battery Blower Motor Control; Hybrid Vehicle Battery Thermistor; Hybrid Vehicle Control Computer; Hydrogen Pipes and Manifolds; Inverter Assembly with Converter; Main Switch Assembly; Power Source Control Computer Assembly; Power Steering Electronic Control Unit Assembly; Power Steering Gear Assembly; Pressure Sensors; Reducing Valve; Shift Lever Position Sensor; Skid Control Computer Assembly; Steering Column Assembly; Transmission Control Module

- 1 Time and Mileage coverage periods for New Vehicle Plans are measured from date vehicle was first put into service as a new vehicle and zero miles. Time and Mileage coverage periods for Pre-Owned Vehicle Plans are measured from the Agreement Application Date and Agreement Application Mileage. Coverage expires upon reaching the maximum time or mileage of the coverage period selected, whichever occurs first. See your Agreement for complete terms, conditions, and restrictions.
- 2 In California, roadside service provided if vehicle is inoperable due to the mechanical failure of a covered component.
- 3 Deductible applies to each eligible repair visit. See your Mazda dealer for plan details.
- 4 Covered components are subject to change. See your Agreement for complete details.

## VEHICLE SERVICE AGREEMENT GOLD

#### GENERAL PLAN BENEFITS

- Mechanical Breakdown Protection
- Repairs performed by factory-trained technicians
- Protection against rising costs of labor and covered parts
- 24/7 Roadside Assistance

# The purchase of a voluntary protection product is optional, cancelable (subject to specific agreement terms) and not required to obtain credit.

This brochure is intended as a sample of Vehicle Service Agreement coverage. Coverage is subject to exclusions and limitations set forth in the Vehicle Service Agreement. The actual coverage, exclusions, and limitations of the Agreements may vary both from state to state and according to the program features chosen. The administrator and obligor of this Vehicle Service Agreement is Toyota Motor Insurance Services, Inc. In certain states, Toyota Motor Services Company administers Vehicle Service Agreements.

# In Florida, the administrator is Toyota Motor Insurance Company P.O. BOX 650478, Dallas, TX, 75265 Florida License #02871

©2023 The trade name "Mazda Financial Services" and the Mazda and Mazda Financial Services logos are owned by Mazda Motor Corporation (Mazda) or its affiliates and are licensed to Toyota Motor Credit Corporation (TMCC). Mazda Protection Products is a registered service mark of Mazda and licensed to Toyota Motor Insurance Services, Inc. (TMIS). Voluntary Protection Products are administered by TMIS or a third party contracted by TMIS. Mazda is solely responsible for its products and services and for promotional statements about them and is not affiliated with TMCC or its affiliates. 00251MPP • 23-741800 (2/23)

